



# ZXP399 DMX Controls and Accessories

## SSLCTR ACTIVESITE GATEWAY

CE mark - UL mark

The ZXP399 DMX Controls and Wiring Accessories are to be used with our architectural and facade lighting luminaires (UniFlood C, M and G, UniStrip G4, UniEdge, UniDot G2, UniString and UniBar).;DMX Controls include a main controller, stand-alone controller, sub-controllers, DMX amplifier and DMX addressing device.;Main Controller: Industrial computer that can control up to 6,000 DMX universes.;Stand-alone Controller: Fits all medium applications with up to 700 DMX universes.;Wiring accessories include leader and jump cables with male and female IP67 connectors and end-caps.;Addressing Device: Hand-held device that can write DMX addresses to a whole run on-site within minutes.;DMX Amplifier: Compact, IP65 and low-power repeater that can amplify the DMX signal for up 100 metres.

### Product data

General Information	
CE mark	CE mark
UL mark	UL mark
Mechanical and Housing	
Colour	Black
Dimensions (height x width x depth)	NaN x NaN x NaN mm (NaN x NaN x NaN in)

Initial Performance (IEC Compliant)	
Initial input power	40 W
Product Data	
Full product code	871829164576400
Order product name	SSLCTR ACTIVESITE GATEWAY
EAN/UPC – product	8718291645764
Order code	912400133649
SAP numerator – quantity per pack	1
Numerator – packs per outer box	1

